







EXES on SOFIA



Matthew J Richter UC Davis

with Mark McKelvey, Mike Case, and Curtis DeWitt







About EXES





- EXES is a PI instrument optimized for high spectral resolution in mid-IR
- High resolution mode:
 - cross-dispersed with R = 50,000 to 110,000 depending on slit width
 - single setting coverage of ~0.8% with 4-40" long slit or ~4% with >1" long slit
- Other modes
 - Medium single order: R ~ 5,000 to 20,000
 - Low single order: R ~ 1500 to 4000
 - limited focal plane and pupil imaging
- Wavelength range ~4.5 μm to ~28.3 μm
 - includes H₂ J=2-0, although detector response fading at that wavelength
- Detector is a 1024 X 1024 pixel Si:As optimized for low background










Other Mid-IR Spectrographs










Other Mid-IR Spectrographs










Echelon grating






- 40" long
- 0.300" groove spacing
 - 0.131 grooves/mm
- 84.2 degree incidence angle
 - 0.03" groove height
- Diamond machined Al 6061
 - Hyperfine Inc








EXES flights





- 7 flights so far
 - 2 Flights in Apr 2014
 - 5 flights in Feb/Mar 2015
- Nod and map observations
- Most observations in 6-8 micron range in high resolution mode
 - What can be done from the ground should be done from the ground
 - 50% Mauna Kea transmission for point sources TEXES on Gemini









Spectral Resolution PHYSICS




5.4 km/s







- Use sky lines with 6 different slits
- FWHM of Gaussian fits
 - 3 km/s to 5.4 km/s
- Titan spectra for further investigation








Standard Stars







 H₂O lines in stars are weaker than expected based on 12 um observations with TEXES

 First stars other than Sun explored at this wavelength range with this resolution

Ryde et al (in prep)






Jupiter H2





- Use H₂ ortho-para ratio to study dynamics
 - Only possible with EXES/SOFIA
- EXES/SOFIA can produce data cubes
 - slit stepped across Jupiter
 - both maps done in single leg

H₂ maps of Jupiter and continuum at 17.03 microns (top) and 28.22 microns (bottom)



Greathouse et al, in prep







Spectral Surveys







- Use low dispersion for cross-dispersion -High_Low mode
- large wavelength coverage at cost of short slit
- powerful tool for bright objects
















- Nod difference
 - atmosphere absorbs













- Nod difference
 - atmosphere absorbs















- Nod difference
 - atmosphere absorbs

















- atmosphere absorbs
- P Cygni profiles













- 80 minute leg
- completed 6 settings
 - 5.6 to 6.7 microns










H₂O toward massive YSO












H₂O toward massive YSO









Summary





- EXES on SOFIA producing new science data
 - unseen combination of sensitivity and spectral resolution at wavelengths blocked from the ground
- Able to separate astrophysical lines from Earth's atmospheric lines with moderate Doppler shift
- Basic observing modes work
 - Still lots of work to be done....